



MKE 600



Quick Guide

Kurzanleitung
 Guide de démarrage rapide
 Guida rapida
 Instrucciones resumidas
 Instruções resumidas
 Beknopte gebruiksaanwijzing
 Krótka instrukcja obsługi
 Snabbguide

Kort vejledning

Pikaohje
 Σύντομες οδηγίες
 Kısa Kılavuz
 Краткая инструкция
 快速指南
 快速使用指南
 クイックガイド
 요약 안내서


Sennheiser electronic SE & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com


Printed in Germany
Publ. 03/24, 587477/A02

SENNHEISER

In the box




Overview






- Adjusting**
- 1 „Low cut“ switch
 - 2 LED operation indicator
 - 3 BATT ON/OFF battery switch
 - 4 XLR-3 socket

Battery




*optional accessory




< 1s			0 h
			> 8 h
1s			150 h


Phantom powering



*optional accessory




Setup



Adjusting

low-cut




Off



On: frequencies below 100 Hz are attenuated to reduce wind and impact noise

Accessory




*optional accessory

Specifications

Pick-up pattern	super-cardioid/lobar
Frequency response	40 – 20,000 Hz
Sensitivity	with P48 powering: 21 mV/Pa with battery powering: 19 mV/Pa
Max. SPL	with P48 powering: 132 dB SPL with battery powering: 126 dB SPL
Equivalent noise level A-weighted	with P48 powering: 15 dB (A) with battery powering: 16 dB (A)
Power supply	48 V ± 4 V (P48, IEC 61938) via XLR-3 or battery/rechargeable battery (AA size, 1.5 V/1.2 V)
Current consumption	with P48 powering: 4.4 mA
Operating time with battery	approx. 150 h
„Low Batt“ indicator	< 1.05 V; approx. 8 h of remaining operating time after initial display
Temperature range	Operation: -10 °C to +60 °C
Dimension	∅ 20 mm x 256 mm
Weight	128 g (without battery)

Cleaning



Polar pattern and frequency response

