








XS WIRELESS 1 DUAL

Quick Guide

Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Quickguide | Quick Guide | Гръбгорос облугос | Краткая инструкция | 快速指南 | 요약 설명서


XS WIRELESS 1 DUAL	Vocal Sets	
	XSW 1-825 DUAL	XSW 1-835 DUAL
EM-XSW1 DUAL 	1	1
SKM-XSW e825 	2	-
SKM-XSW e835 	-	2
MZQ 1 	2	2
AA LR6 1.5 V 	4	4



Change frequency


Automatically/Scan

Off





Manually

Bank Channel




Sync




Multichannel

Bank 1...8
Ch. 0...9




Sensitivity


0 dB
-10 dB



Squelch



Min. distance



SKM

