

### Antennas

\*optional accessories:  
ADP UHF (470 - 1075 MHz)  
AD 1800 (1400 - 2400 MHz)

**EW-D Smart Assist**

Download on the **App Store** | GET IT ON **Google Play**

**Sennheiser Documentation App**

Download on the **App Store** | GET IT ON **Google Play**

or online at  
[www.sennheiser.com/download](http://www.sennheiser.com/download)  
EW-DX

**Evolution Wireless Digital**

EW-DX EM 2  
EW-DX SK  
EW-DX SKM

Quick Guide  
Kurzanleitung  
Guide rapide  
Guida rapida  
Guía de inicio rápido  
Guia rápido  
Beknopte handleiding  
Krótka instrukcja obsługi  
Snabbguide

Kort vejledning  
Pikaohje  
Γρήγορος οδηγός  
Kisa Kilavuz  
Краткая инструкция  
快速指南  
クイックガイド  
퀵 가이드

**SENNHEISER**

Am Labor 1, 30900 Wedemark, Germany  
[www.sennheiser.com](http://www.sennheiser.com)

Printed in Germany  
Publ. 04/22, 587467/A01

### Audio Out

6.3 mm | XLR-3

OR

### Power supply

EU | US | UK | AU | KOR | CN

### Remote control

**EW-D Smart Assist App**

Download on the **App Store** | GET IT ON **Google Play**

**Wireless Systems Manager (WSM)**  
[www.sennheiser.com/wsm](http://www.sennheiser.com/wsm)

**Sennheiser Control Cockpit (SCC)**  
[www.sennheiser.com/control-cockpit-software](http://www.sennheiser.com/control-cockpit-software)

### In the box

Rack mount angles  
Power supply adapters  
Power supply

### Battery

2 AA batteries | BA 70 rechargeable battery

1 2 3 4

2 AA batteries | BA 70 rechargeable battery

### EW-DX EM 2

Headphone output | LED ch. 1 | Channel 1 select | UP/DOWN | SET | ESC

Headphone volume control | LED ch. 2 | Channel 2 select | Display | SYNC | ON/OFF

PoE / Network control (WSM / SCC) | Audio outputs | Antenna inputs

### On/Off

Off -> On	<b>EM/SK/SKM(-S)</b>
short	on
On -> Off	<b>EM/SK/SKM(-S)</b>
long	off

### Display of SK / SKM(-S)

Device on: CH.NAME 478.125

Device off: CH.NAME 478.125

The display of the SK and SKM(-S) will stay on when the device is switched off.

### EW-DX SKM-S | EW-DX SKM

ON/OFF | DATA LED | ESC | UP | Display

LINK LED | SYNC | DOWN | SET | MUTE (EW-DX SKM-S)

### EW-DX SK | EW-DX SK 3-PIN

EW-DX SK: 3.5 mm jack

EW-DX SK 3-PIN: 3 pin socket

LINK LED | DATA LED | SYNC | MUTE | Display

ON/OFF | ESC | SET | DOWN | UP

