

Setup

3.5 mm
3.5 mm
3.5 mm
XLR

OR

Mute

SK SKM-S

EW-D Smart Assist

Download on the App Store GET IT ON Google Play

Sennheiser Documentation App

Download on the App Store GET IT ON Google Play

or online at www.sennheiser.com/download
EW-DP_

Sennheiser electronic GmbH & Co. KG
Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Printed in Germany
Publ. 12/22, 592859/A02

Evolution Wireless Digital Portable

EW-DP EK, EW-D SK, EW-D SKM-S

Quick Guide
Kurzanleitung
Guide rapide
Guía rápida
Guía de inicio rápido
Guia rápido
Beknopte handleiding
Krátká instrukcja obsługi
Snabbguide

Kort vejledning
Pikaohje
Γρήγορος οδηγός
Kisa Kilavuz
Краткая инструкция
簡要說明
快速使用指南
クイックガイド
요약 안내서

SENNHEISER

Power Supply / Charging

EK

USB-C Power

OR

Powerbank

Battery

EK

BA 70 rechargeable battery (included)

optional: 2 AA batteries

EW-D Smart Assist

The EW-D Smart Assist app simplifies your workflow

- EW-D Smart Assist app provides automated setup, operation and monitoring using any iOS or Android device
- Intelligent setup automatically creates reliable wireless connections, no wireless expertise required
- Mobile access to all system settings centralizes control and eliminates the need for complicated menu navigation on each device
- Easy frequency allocation and wireless channel naming help to keep systems organized

Download on the App Store GET IT ON Google Play

EW-DP EK

1G8 Variant

UHF Variant

Battery

1 2 3

2 AA batteries (included)

*optional: BA 70 rechargeable battery

Battery

1 2 3 4

2 AA batteries (included)

*optional: BA 70 rechargeable battery

EW-DP EK

LINK LED

DATA LED

UP

DOWN

SET

SYNC

ESC ON/OFF

Headphone Output

USB-C Power/Charging

MIC OUT

USB POWER

Microphone Output

On/Off

EK SKM-S SK

Off -> On

short EK/SK/SKM-S on

On -> Off

long EK/SK/SKM-S off

Identify/Battery check

On -> Identify/Check

SK/SKM-S

short Identify/Check

LINK LED SK/SKM-S	≤ 100 %
≤ 60 %	
≤ 20 %	

Display of synced EK

EW-DP EK

ON/OFF

DATA LED

SYNC

LINK LED

MUTE

EW-D SK

DATA LED

LINK LED

SYNC

MUTE

ON/OFF

Display

Default screen PRESS

Labels on display: Display page, Mute switch, Receiver battery (EK), Transmitter battery (SK or SKM-S), Audio output level, PEAK display, Designation, Frequency, Channel, Gain, RF Signal strength

→ Instruction Manual

LEDs

LINK LED	Meaning
	- Link ok - audio active
	- Link ok - audio muted or no capsule on SKM
	- Link ok - audio clip
	- No link
	- Link ok - Low transmitter battery
	- Device switched off

DATA LED	Meaning
	Bluetooth active to - sync with transmitter - connect with app
	Firmware update in progress

EK LINK DATA

SKM-S DATA LINK

SK DATA LINK

Sync

SKM-S short press

OR

SK short press

Menu

Gain → Output level → Gain +21 dB → +18 dB

Output level → Headphone → Output level -15 dB → -20 dB

Headphone → Mute switch → Headphone → Mute switch ignored → active

Mute switch → Auto scan → Mute switch ignored → active

Auto scan → Channel → Auto scan 526.000 MHz (94)

Channel → Frequency → Channel 94 526.000 MHz → 1

Frequency → Brightness → Frequency 470 .200 MHz → 526

Brightness → Reset → Brightness 60 % → 40

Reset → Reset to factory defaults? → Yes SET / No ESC

Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso | Instrucciones de manejo | Manual de instruções | Gebruiksaanwijzing | Instrukcja obsługi | Bruksanvisning | Betjenings vejledning | Käyttöohje | Οδηγίες λειτουργίας | Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 | 使用説明書 | 取扱説明書 | 사용 설명서

EW-D Smart Assist
Available on the App Store | Android App on Google play

Sennheiser Documentation App
Available on the App Store | Android App on Google play

Cables

3.5 mm Y-Cable* Art.-No. 700061

3.5 mm - XLR male Art.-No. 700062

3.5 mm jack Art.-No. 508648

* for stacking two EK's

Mounting plate

OR

Stacking

→ Mounting instructions

Handling

SKM-S

ME 2

ME 3

ME 4

25 cm (10")

2...3 cm (1")