


Wireless Presentation Pod WPP30



Quick Start Guide (V1.0)

English | 简体中文 | Deutsch | Français | Español



Declaration of Conformity

We, YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD
Address: 309, 3rd Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R. China
Manufacturer: YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD
Address: 309, 3rd Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R. China
DATE: 26th /May/2022
declare that the product
Type: Wireless Presentation Pod
Model: WPP30

meets the essential requirements and other relevant provisions according to the following EC directive
Directive: 2014/30/EU, 2014/35/EU, RED 2014/53/EU
Conformity

The product complies with the following standards:
Safety : EN IEC 62368-1:2020+A11:2020
EMC : EN 55032:2015

EN 55035:2017
EN61000-3-2:2014
EN61000-3-3:2013
Radio: ETSI EN 301 489-1 V2.2.0,
ETSI EN 301 489-17 V3.2.0,
ETSI EN 300 328 V2.1.1;
ETSI EN 301 893 V2.1.1
EN 300 440 V2.1.1
EN 303 687 V0.0.14
Health :EN 62311:2008; EN62479:2010

Directive 2011/65/EU and (EU)2015/863 of the European Parliament and of the Council of 8 June 2011 and 4 June 2015 on the restriction of the use of certain hazardous substances in electrical and electronic equipment(RoHS 2.0)
Directive 2012/19/EU of the European Parliament and of the Council of 4 July 2012 on Waste electrical and electronic equipment(WEEE)
Regulation (EC) No.1907/2006 of the European Parliament and of the Council of 18 December 2006 on Registration, Evaluation, Authorization, and Restriction of Chemicals (REACH)

NAME: Huahu Wang
DATE: 26th /May/2022
WongHuahu


TITLE: Manager



431014001977

YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.
Web: www.yealink.com
Copyright©2022 YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.All rights reserved.

1 Package Contents



WPP30 Quick Start Guide


2 Pair WPP30 to the Endpoint

WPP30 supports RoomCast/MeetingBar series/MeetingEye series/MVC series endpoint.

If you purchase one of above endpoints and WPP30 together, they are already paired. Just connect the WPP30 to your computer for sharing content.


If you purchase the WPP30 separately, you need to pair endpoint and WPP30 manually.

To pair endpoint and WPP30 manually:




1. Connect the WPP30 to the USB-A port on the endpoint.
2. Disconnect the WPP30 after the monitor prompts "Wireless Presentation Pod is Paired successfully".

3 Start or Stop Sharing Content



1. Connect the WPP30 to the USB-A/USB-C port on your computer.
Wait Yealink Wireless Presentation Pod software pops up.



2. On the WPP30, press the presentation button to share full screen.

Press the presentation button again to stop sharing.

1 包装清单




WPP30 快速入门指南

2 配对无线传屏助手和终端

WPP30 支持 RoomCast/MeetingBar 系列 /MeetingEye 系列 /MVC 系列终端。


如果你购买的是无线传屏助手和以上任一终端的组合，二者默认自动配对，将无线传屏助手直接连在电脑上即可用于演示。如果你单独购买了无线传屏助手，你需要手动配对无线传屏助手和终端，以实现二者的自动连接。

配对无线传屏助手和会议电视终端：




1. 将无线传屏助手插到终端的 USB-A 口上。
2. 当显示设备提示“无线传屏器配对成功”后，拔下无线传屏助手。

3 开始或结束演示



1. 将无线传屏助手插到电脑的 USB-A/USB-C 接口上。
电脑自动开启亿联无线传屏器软件。



2. 按无线传屏助手上的演示键，共享整个电脑屏幕。

再次按下演示键结束投屏。

1 Verpackungsinhalt



WPP30 Kurzanleitung


2 WPP30 mit dem Endpunkt koppeln

WPP30 unterstützt die Endpunkte der RoomCast/ MeetingBar-Serie/MeetingEye-Serie/MVC-Serie.

Wenn Sie einen der oben genannten Endpunkte und den WPP30 zusammen erwerben, sind diese bereits miteinander gekoppelt. Schließen Sie den WPP30 einfach an Ihren PC an, um Inhalte freizugeben.


Wenn Sie den WPP30 separat erwerben, müssen Sie den Endpunkt und den WPP30 manuell koppeln.

So koppeln Sie den Endpunkt und den WPP30 manuell:




1. Verbinden Sie den WPP30 mit dem USB-A-Anschluss des Endpunkts.
2. Trennen Sie den WPP30, wenn der Monitor die Meldung „Wireless Presentation Pod wurde erfolgreich gekoppelt.“

3 Inhaltsfreigabe starten oder beenden



1. Verbinden Sie den WPP30 mit dem USB-C/USB-A-Anschluss Ihres PCs.
Warten Sie, bis sich Yealinks Adapter-Software für kabellose Präsentationen öffnet.



2. Drücken Sie auf dem WPP30 die Präsentationstaste, um das Vollbild zu teilen.

Drücken Sie die Präsentationstaste erneut, um die Freigabe zu beenden.

